

INSTRUCTION SHEET

This sheet provides instructions for inserting Change 2 to the General Maintenance Handbook, NAVSHIPS 0967-000-0160 of the Electronics Installation and Maintenance Book.

The purpose of this change is to update the General Maintenance Handbook through the addition of new and revised material to SECTIONS 2 and 7. All affected FRONT MATTER has also been revised to reflect this change.

The procedures for executing this change are set forth in the following paragraphs:

1. FRONT MATTER

Remove Title Page and pages ii through viii, Change 1, Insert Title Page and pages ii thru viii, Change 2.

2. SECTION 2. GENERAL MAINTENANCE PROCEDURES

Remove pages 2-1 through 2-10, originals.
Insert pages 2-1 through 2-10L, Change 2.

Remove pages 2-49 through 2-51, originals.
Insert pages 2-49, original, and 2-50 through 2-56, Change 2.

3. SECTION 7. PARTS MAINTENANCE

Remove pages 7-1 through 7-37, originals.
Insert pages 7-1 through 7-57, Change 2.

4. Destroy superseded pages only after a check has been made against the List of Effective Pages to assure that the new pages have been inserted.

5. Record the insertion of this change on the RECORD OF CORRECTIONS MADE page.

RECEIVED

MAY 19 1967

USNS POPE T-AP110

Page 1 (of 1)