

ITEM NO.      FATHOMETER ACTIVATION

Accomplish the following work to activate the Raytheon model 714/715

Fathometer:

- A. Burn off 1/2 inch thick protection plate over transducer on the bottom of the hull at the cofferdam location Frame 46½ Port side. Grind smooth the weld slag in way of the plate removal and grease transducer head during underwater hull painting sequence.
- B. Open the fathometer cofferdam located Port side, Frame #46½. Clean cofferdam of all rust, water, dirt and debris and prime coat cofferdam. Finish coat cofferdam with a coat of white enamel.
- C. Furnish qualified technician to check out and test operate fathometer system and submit a report of conditions found and recommendations with seven (7) copies to MarAd representative.
- D. Upon completion of all work and testing close up cofferdam renewing gasketing and any defective or missing fastening material.