

ENGINE UTILITYMAN (DECK ENGINEER) RESPONSIBILITIES

10/67
234

DAILY

1. Inspect steering engine & telemotor & lubricate all parts per Manufacturers' Instructions.
2. Inspect all laundry equipment for proper operations confer with laundry foreman.
3. Inspect all mechanical galley equipment for proper operation. Confer with Chief Cook & Chief Baker.
- * 4. Observe proper operation of all watertight doors throughout the engine spaces during closure drills.
5. Inspect emergency diesel generator.
- * 6. Test each motor boat engine for one minute.
7. Inspect rudder stock bearing for sufficient lubrication.
8. Check all cargo winches daily when in use & prior to arrival in port in conjunction with electrician.
9. Drain air receivers outside engine spaces.

WEEKLY

1. Test operate diesel generator in conjunction with Chief Electrician for thirty minutes. Lubricate governor links.
2. Lubricate motor boat & lifeboat davit in conjunction with Ship's Carpenter.
3. Lubricate all hand operated remote control gear on W.T. door lands (Engine Room Only)
4. Lubricate parts of all remote control gear in steering engine room.
5. Oil all couplings on steering engine motors and other equipment listed under responsibilities.
- * 6. Observe the operation & testing of all safety devices on dumbwaiters, freight & passenger elevators In conjunction with Chief Electrician. Lubricate all links & pins as necessary.
7. Observe the operation & testing of all safety devices on laundry equipment in conjunction with the laundry foreman.
8. Lubricate, free up, & test the foot brake mechanism on all deck winches.
9. Perform weelly lubrication on steering engine per manufacturers' instructions & chart. Check hydraulic system for leaks; adjust glands.
10. Observe that required lubrication is being conducted on galley equipment & laundry equipment. Provide assistance to the Chief Cook & Laundryman If required.
11. Operate all cargo winches in conjunction with the Chief Electrician.

CONTINUED ON REVERSE SIDE)

WEEKLY (CONT.)

DATE: CONDITION:

12. Sound diesel generator fuel tank, replenish when necessary.
13. Inspect telemotor system for leaks, adjust glands, both sending & receiving. Check with Deck Department as to degree of response.

MONTHLY (First Week of Month)

DATE:

1. Inspect oil level of following deck machinery and add oil if necessary, as per check off list:

ANCHOR WINDLASS, High Speed Gear Case (SAE 30 OIL)

CARGO WINCHES, Gear Case (SAE 90)

CAPSTAN, Gear Case (SAE 160 or 5190)

LIFEBOAT WINCHES, Gear Case (SAE 80)

LIFEBOAT HAND PROPELLING, Gear Box (SAE 20)

2. Perform monthly maintenance & lubrication on Elevators & dumbwaiters per manufacturers' instruction books
3. Sound main diesel oil storage tank & give report to Chief Engineer
4. Sound L.O. STORAGE & Settling Tanks

QUARTERLY

DATE LAST INSPECTED

1. Change Lube OIL in diesel generator
2. Change Oil in lifeboat motors.

* LOG ENTRY REQUIRED

DATE _____

SIGNATURE: _____

10/67

ENGINE UTILINMAN (DECK ENGINEER) RESPONSIBILITIES

9.10.11

DAILY

1. Inspect steering engine & telemotor & lubricate all parts per Manufacturers' Instructions.
2. Inspect all laundry equipment for proper operations confer with laundry foreman.
3. Inspect all mechanical galley equipment for proper operation. Confer with Chief Cook & Chief Baker.
- * 4. Observe proper operation of all watertight doors throughout the engine spaces during closure drills.
5. Inspect emergency diesel generator.
- * 6. Test each motor boat engine for one minute. *notify Bridge*
7. Inspect rudder stock bearing for sufficient lubrication.
8. Check all cargo winches daily when in use & prior to arrival in port in conjunction with electricien.
9. Drain air receivers outside engine spaces.

WEEKLY

Change oil in lifeboats 10/10/67

10/10/67
in conjunction

DATE: CONDITION:

1. Test operate diesel generator in conjunction with Chief Electrician for thirty minutes. Lubricate governor links.
2. Lubricate motor boat & lifeboat davit in conjunction with Ship's Carpenter.
3. Lubricate all hand operated remote control gear on W.T. door lands (Engine Room Only)
4. Lubricate parts of all remote control gear in steering engine room.
5. Oil all couplings on steering engine motors and other equipment listed under responsibilities.
- * 6. Observe the operation & testing of all safety devices on dumbwaiters, freight & passenger elevators In conjunction with Chief Electrician. Lubricate all links & pins as necessary.
7. Observe the operation & testing of all safety devices on laundry equipment in conjunction with the laundry foreman.
8. Lubricate, free up, & test the foot brake mechanism on all deck winches.
9. Perform weekly lubrication on steering engine per manufacturers' instructions & chart. Check hydraulic system for leaks; adjust glands.
10. Observe that required lubrication is being conducted on galley equipment & laundry equipment. Provide assistance to the Chief Cook & Laundryman If required.
11. Operate all cargo winches in conjunction with the

WEEKLY (CONT.)DATE: CONDITION:

12. Sound diesel generator fuel tank, replenish when necessary.

13. Inspect telemotor system for leaks, adjust glands, both sending & receiving. Check with Deck Department as to degree of response.

MONTHLY (First Week of Month)DATE:

1. Inspect oil level of following deck machinery and add oil if necessary, as per check off list:

ANCHOR WINDLASS, High Speed Gear Case (SAE 30 OIL)

CARGO WINCHES, Gear Case (SAE 90)

CAPSTAN, Gear Case (SAE 160 or 5190)

LIFEBOAT WINCHES, Gear Case (SAE 80)

LIFEBOAT HAND PROPELLING, Gear Box (SAE 20)

2. Perform monthly maintenance & lubrication on Elevators & dumbwaiters per manufacturers' instruction books

3. Sound main diesel oil storage tank & give report to Chief Engineer

4. Sound L.O. STORAGE & Settling Tanks

QUARTERLYDATE LAST INSPECTED

1. Change Lube OIL in diesel generator

2. Change Oil in lifeboat motors.

* LOG ENTRY REQUIRED

DATE SIGNATURE:

ENGINE UTILITYMAN (DECK ENGINEER) RESPONSIBILITIES

10/67

121313 161718
THE END OF THE MONTH

DAILY

1. Inspect steering engine & telemotor & lubricate all parts per Manufacturers' Instructions.
2. Inspect all laundry equipment for proper operations confer with laundry foreman.
3. Inspect all mechanical galley equipment for proper operation. Confer with Chief Cook & Chief Baker.
- * 4. Observe proper operation of all watertight doors throughout the engine spaces during closure drills.
5. Inspect emergency diesel generator.
- * 6. Test each motor boat engine for one minute.
7. Inspect rudder stock bearing for sufficient lubrication.
8. Check all cargo winches daily when in use & prior to arrival in port in conjunction with electricien.
9. Drain air receivers outside engine spaces.

WEEKLY

1. Test operate diesel generator in conjunction with Chief Electrician for thirty minutes. Lubricate governor links.
2. Lubricate motor boat & lifeboat davit in conjunction with Ship's Carpenter.
3. Lubricate all hand operated remote control gear on W.T. door lands (Engine Room Only)
4. Lubricate parts of all remote control gear in steering engine room.
5. Oil all couplings on steering engine motors and other equipment listed under responsibilities.
- * 6. Observe the operation & testing of all safety devices on dumbwaiters, freight & passenger elevators In conjunction with Chief Electrician. Lubricate all links & pins as necessary.
- * 7. Observe the operation & testing of all safety devices on laundry equipment in conjunction with the laundry foreman.
8. Lubricate, free up, & test the foot brake mechanism on all deck winches.
9. Perform weelly lubrication on steering engine per manufacturers' instructions & chart. Check hydraulic system for leaks; adjust glands.
10. Observe that required lubrication is being conducted on galley equipment & laundry equipment. Provide assistance to the Chief Cook & Laundryman If required.
11. Operate all cargo winches in conjunction with the Chief Electrician.

CONTINUED ON REVERSE SIDE)

WEEKLY (CONT.)

DATE: CONDITION:

12. Sound diesel generator fuel tank, replenish when necessary.
13. Inspect telemotor system for leaks, adjust glands, both sending & receiving. Check with Deck Department as to degree of response.

MONTHLY (First Week of Month)

DATE:

1. Inspect oil level of following deck machinery and add oil if necessary, as per check off list:

ANCHOR WINDLASS, High Speed Gear Case (AAE 30 OIL)

CARGO WINCHES, Gear Case (SAE 90)

CAPSTAN, Gear Case (SAE 160 or 5190)

LIFEBOAT WINCHES, Gear Case (SAE 80)

LIFEBOAT HAND PROPELLING, Gear Box (SAE 20)

2. Perform monthly maintenance & lubrication on Elevators & dumbwaiters per manufacturers' instruction books
3. Sound main diesel oil storage tank & give report to Chief Engineer

QUARTERLY

DATE LAST INSPECTED

1. Change Lube Oil in diesel generator
2. Change Oil in lifeboat motors.

* LOG ENTRY REQUIRED

DATE _____

SIGNATURE:

ENGINE UTILITYMAN (DECK ENGINEER) RESPONSIBILITIES

9/67

15262

DAILY

1. Inspect steering engine & telemotor & lubricate all parts per Manufacturers' Instructions.
2. Inspect all laundry equipment for proper operations confer with laundry foreman.
3. Inspect all mechanical galley equipment for proper operation. Confer with Chief Cook & Chief Baker.
- * 4. Observe proper operation of all watertight doors throughout the engine spaces during closure drills.
5. Inspect emergency diesel generator.
- * 6. Test each motor boat engine for one minute.
7. Inspect rudder stock bearing for sufficient lubrication.
8. Check all cargo winches daily when in use & prior to arrival in port in conjunction with electrician.
9. Drain air receivers outside engine spaces.

WEEKLY.

1. Test operate diesel generator in conjunction with Chief Electrician for thirty minutes. Lubricate governor links.
2. Lubricate motor boat & lifeboat davit in conjunction with Ship's Carpenter.
3. Lubricate all hand operated remote control gear on W.T. door lands (Engine Room Only)
4. Lubricate parts of all remote control gear in steering engine room.
5. Oil all couplings on steering engine motors and other equipment listed under responsibilities.
6. Observe the operation & testing of all safety devices on dumbwaiters, freight & passenger elevators In conjunction with Chief Electrician. Lubricate all links & pins as necessary.
7. Observe the operation & testing of all safety devices on laundry equipment in conjunction with the laundry foreman.
8. Lubricate, free up, & test the foot brake mechanism on all deck winches.
9. Perform weelly lubrication on steering engine per manufacturers' instructions & chart. Check hydraulic system for leaks; adjust glands.
10. Observe that required lubrication is being conducted on galley equipment & laundry equipment. Provide assistance to the Chief Cook & Laundryman If required.
11. Operate all cargo winches in conjunction with the Chief Electrician.

CONTINUED ON REVERSE SIDE)

WEEKLY (CONT.)

DATE: CONDITION:

12. Sound diesel generator fuel tank, replenish when necessary.
13. Inspect telemotor system for leaks, adjust glands, both sending & receiving. Check with Deck Department as to degree of response.

MONTHLY (First Week of Month)

1. Inspect oil level of following deck machinery and add oil if necessary, as per check off list:

ANCHOR WINDLASS, High Speed Gear Case (SAE 30 OIL)

CARGO WINCHES, Gear Case (SAE 90)

CAPSTAN, Gear Case (SAE 160 or 5190)

LIFEBOAT WINCHES, Gear Case (SAE 80)

LIFEBOAT HAND PROPELLING, Gear Box (SAE 20)

2. Perform monthly maintenance & lubrication on Elevators & dumbwaiters per manufacturers' instruction books
3. Sound main diesel oil storage tank & give report to Chief Engineer

4. Sound L.O. STORAGE & Settling Tanks

QUARTERLY

DATE LAST INSPECTED

1. Change Lube OIL in diesel generator
2. Change Oil in lifeboat motors.

* LOG ENTRY REQUIRED

DATE

SIGNATURE: