

DECK #1
FIRE STATION
1-30-1
1-30-2
1-58-0

CO2 EXTINGUISHERS
1-6-0 1-58-1
1-12-1
1-18-2
1-20-2
SODA ACID EXTINGUISHERS

1-21-1
1-25-2
1-44-1
1-44-2
FIRE AXE
1-23-2
1-27-1

MANUAL (BREAK GLASS) ALARM
1-15-1
1-35-2

SUBMERSIBLE PUMP OUTLETS
1-6-0 3-44-1

FIRE MAIN CUTOUTS

LIGHTING PANELS
1B3 1L3
1-17-2 1-40-2
1B4
1-34-2
FOG APPLICATORS

ZONE # ONE
WEATHER DECK DOORS AND HATCHES
1-6-1

FIRE SCREEN DOORS
1-18-1 1-45-2
1-18-2 1-58-1
1-25-1 1-58-2
1-45-1
WATERTIGHT DOORS
1-12-2
1-15-2
1-16-2

VENT CLOSURES WEATHER DECK

PORT HOLES
1-21-1 1-36-1 1-45-1 1-55-1
1-21-2 1-36-2 1-45-2 1-55-2
1-27-1 1-38-1 1-48-1 1-58-1
1-27-2 1-38-2 1-48-2 1-58-2
1-32-1 1-41-1 1-51-1
1-32-2 1-41-2 1-51-2

REMOTE CONTROL SCUPPER VALVES

REMOTE CONTROL BILGE VALVES

VENTILATION BLOWER EXHAUSTS
1-19-
1-36-1
1-36-2
1-42-1
1-42-2

COMMUNICATION
S.P. D.C. S.S.
1-23-2 1-23-2 1-22-2

CO2 INDEPENDENT SYSTEM
1-14-2

ABC HOSE BRACKETS

DECONTAMINATION STATIONS
2-42-1 Station #1

SHORES
02-38-1
2-42-0

SOUNDING TUBE HOLDS
#1 Hold #2 Hold
2-42-1 2-42-2 2-60-1 2-60-2
REPAIR LOCKERS

02-98-2 Repair #1
4-105-1 Repair #2
CO2 MANIFOLD CO2 BOTTLE RM.
1-84-2 6-93-3

STRETCHERS
1-25-0


SUBMERSIBLE PUMP EDUCTOR
01-26-2 01-25-1

ATOMIC DEFENSE LOCKER
02-103-2

VENTILATION BLOWER SUPPLY
1-42-4
1-59-1
1-60-1
1-59-2
1-60-2

01 Deck

FRAME 1-60



BOA

U.S.N.S.

DECK # 01

FIRE STATION

01-22-0
01-45-1
01-45-2

CO2 EXTINGUISHERS

01-41-1

SODA ACID EXTINGUISHERS

FIRE AXE

MANUAL (BREAK GLASS) ALARM

SUBMERSIBLE PUMP OUTLETS

1-6-0 3-44-1

FIRE MAIN CUTOUTS

LIGHTING PANELS

114
01-41-1

FOG APPLICATORS

ZONE # ONE

WEATHER DECK DOORS AND HATCHES

01-1-2 01-36-2 01-55-1
01-27-1 01-41-1
01-27-2 01-46-1
01-35-1 01-47-2

FIRE SCREEN DOORS

WATERTIGHT DOORS

VENT CLOSURES WEATHER DECK

02-19-0 01-27-2 02-40-0
01-7-1 01-34-0 01-46-2
01-7-2 01-34-1 01-47-1
01-10-1 01-37-1 01-53-0
01-10-2 01-39-1 01-58-1
01-15-0 01-39-2 01-58-2
01-17-1 01-37-2 01-59-2
01-20-2 01-40-1 01-22-1
01-20-4 01-40-2
01-27-0 01-45-2
01-27-1 01-46-1

REMOTE CONTROL SCUPPER VALVES

REMOTE CONTROL BILGE VALVES

VENTILATION BLOWER EXHAUSTS

COMMUNICATION

S.P. D.C. S.S.
01-0-1 01-56-1

CO2 INDEPENDENT SYSTEM

ABC HOSE BRACKETS

01-2-2 01-42-1 Kingpost
01-42-2 Kingpost

DECONTAMINATION STATIONS

2-42-1 Station #1

SHORES

02-38-1
2-42-0

SOUNDING TUBE HOLDS

REPAIR LOCKERS

02-98-2 Repair #1
4-105-1 Repair #2

CO2 MANIFOLD

1-84-2

CO2 BOTTLE RM.
6-93-3

STRETCHERS

1-25-0

SUBMERSIBLE PUMP

01-26-2

EDUCTOR

01-25-1

ATOMIC DEFENSE LOCKER

02-103-2

VENTILATION BLOWER SUPPLY

TOTAL 3033

CREW
MILITAR

Zone 1

FRAMES 1 - 60

