

INSTRUCTIONS FOR OPENING
LA RONDE WALL FIXTURE WITH LOCKING DEVICE

After the Fixture has been mounted on the wall, insert the flat side of key in opening at approximately 3:00 o'clock on face of Fixture, under the spring clip.

Pressure on spring clip with key toward 9:00 o'clock will disengage it and permit top to be opened.

Please note that when Odor Control Unit is placed inside Fixture and Fixture closed, that protection is immediately afforded against pilferage, since the Fixture cannot be opened until the Odor Control Unit is substantially reduced in size.

If Fixture is mounted on the wall by use of mounting screws rather than the pressure sensitive tape, it will, of course, be necessary that the top be opened prior to placing the Fixture on the wall.